



Moto Armor RZR XP 1000 (2024+ Only)

Glass Windshield Instructions

SKU: MA-RZXP-WS-GLS

For: RZR XP 1000 (2024+)

IMPORTANT: Please read through all instructions before installing. Thank you.

Hardware:

- 2x - 1.75" Rubber Coated Clamps
- 2x - 1/4-20 Clip Nuts Short
- 2x - 1/4-20 x 1" Bolts Blk
- 2x - 1/4-20 x 3/4" Bolts Blk
- 2x - 1/4-20 Locknuts
- 2x - Split Lock Washers
- 6x - Flat Washers

Step 1: Loosen the front of the roof to allow room to slide the windshield under. Put the clip nuts on the windshield. The threads will be on the front of the windshield. Place the 2 clamps in approximate locations on the cage.

Step 2: Using 2 people put the windshield on the machine. Bolt the windshield into the bottom clamps with the 1" bolts and a flat washer on both sides. Leave loose to allow the top bolts to line up.

Step 3: Bolt the 3/4" bolts to attach the windshield to the holes in the cage. Use a flat washer and lock washer on each bolt. If the bolts are difficult to thread, try moving the nut clips so they are centered with the holes in the cage.

Step 4: Once all bolts are started and the windshield is in the desired location fasten all of the bolts. Resecure the roof.

