



MADE FOR FIRST. BUILT TO LAST.

DISCLAIMER:

PRODUCTS MADE BY L AND W FAB AND MACHINE INC. ARE INTENDED TO FIT YOUR STOCK UTV UNLESS OTHERWISE SPECIFIED. INSTALLING, MODIFYING, OR REMOVING ANY COMPONENTS (FACTORY OR AFTERMARKET) NOT SUPPORTED BY L AND W AND THE INSTRUCTIONS HEREIN WILL VOID YOUR WARRANTY. FOR MORE INFORMATION ON INSTALLATION, WARRANTY, OR PRODUCT USE PLEASE CALL US AT (770) 445-9778

POLARIS RZR TIE RODS.



CONFIGURATION GUIDE

TIE ROD CONFIGURATIONS:

Straight Spindle End (2014 Models):

- 14mm: When installing tie rods on an RZR with a 14mm rack end and straight hole on the steering knuckle you will use the hardware in "Configuration 14S"

Tapered Spindle End (2015+ Models):

- 14mm: When installing tie rods on an RZR with a 14mm rack end and tapered hole on the steering knuckle you will use the hardware in "Configuration 14T"
- 16mm: When installing tie rods on an RZR with a 16mm rack end and tapered hole on the steering knuckle you will use the hardware in "Configuration 16T"

NOTE: The lock washer is ABSOLUTELY REQUIRED on all 14mm rack ends. Be sure to put it on the rack end before installing the tie rod.

Configuration 14S



Configuration 14T



Configuration 16T



TEMPLE, GA 30179



(770) 445-9778

THANK YOU FOR CHOOSING L&W FAB AND MACHINE INC!