



# 2020 RZR PRO XP PRE AIRBOX HIGH FLOW INTAKE TUBE INSTRUCTIONS

Thank you for purchasing your pre airbox high flow intake tube from AA! This tube is designed to eliminate the problem of the factory intake tube collapse. Factory intake tube collapse can happen when boost pressure is increased, and is more likely when your air temps are higher as the rubber has more flex. Installation is extremely easy, just follow the instructions and diagram below.

- First remove your factory intake tube located on the passenger side of the vehicle
- Next, install the large reducer silicone coupler to the vehicle and largest clamp on the larger end
- Once that's in place we recommend leaving all the other clamps slightly loose until everything is aligned
- Install the 45 degree reducer coupler and clamp on the airbox inlet with the larger side going on the airbox. This should be slightly kicked downward and back.
- Install the clamp and upper aluminum tube with the longer straight end going into the large reducer
- Next install the 90 degree coupler on the end of the upper tube with clamps on each end
- Install the lower aluminum tube and clamp with the straight end going into the 90 degree coupler, and the other end going into the 45 degree airbox coupler.
- Align all parts to make sure you have clearance between the frame and shock
- Make sure all tubes are far enough into the couplers so they won't come out when clamped
- Tighten all clamps, then go ride!

