

## L&W Fab Sway Bar Links

The sway bar links will come with two different sized bushings.

- The thicker bushings go on the motor side of the sway bar links.
- The thinner bushings go on the tire side of the sway bar links

Simply unbolt the existing sway bar, place the bushings in the correct orientation and reinstall the OEM bolts.

**XP 1000 / Turbo** Sway Bar Link Bolt Torque Spec - 40 ft-lbs (54 Nm)

**Turbo S / Pro XP / Pro S** Sway Bar Link Bolt Torque Spec - 55 ft-lbs (75 Nm)

**Turbo R / Pro R** Sway Bar Link Bolt Torque Spec - 81 ft-lbs (110 Nm)