




# 2024+ RZR XP Outside Vent Cover Installation

## Parts List:

- (1) Vent Cover Outline
- (1) Vent Cover Mesh
- (6) Mounting Screws





# 2024+ RZR XP Outside Vent Cover Installation

**NOTE:** Outside Vent Covers are shown but the below instructions apply to the Inside Vent Covers as well.

## Step 1:

Align *Vent Cover Outline* into position over vent and hold in place as shown in **Figure 1**. Using the holes in the *Vent Cover Outline* as a guide, drill a 7/64" hole through a couple of the mounting holes.

**Figure 1:**



*Vent Cover Outline held in place by hand for initial couple of holes*





# 2024+ RZR XP Outside Vent Cover Installation

**CAUTION:** *Be sure to not over-tighten the mounting screws!*

## Step 2:

Using a T15 torx bit, secure *Vent Cover Outline* into place with a couple of the provided *Mounting Screws*, as shown in **Figure 2**, and finish drilling all mounting holes.

**Figure 2:**



*Vent Cover Outline temporarily secured in place*

## Step 3:



# 2024+ RZR XP Outside Vent Cover Installation

Place *Vent Cover Mesh* behind the *Vent Cover Outline* and align with holes drilled in **Step 1** and secure into place with supplied *Mounting Screws* as shown in **Figure 3**.

**Figure 3:**



*Vent Cover Outline and Mesh completely installed*





# 2024+ RZR XP Outside Vent Cover Installation



*Outside Vent Cover installed*



# 2024+ RZR XP Outside Vent Cover Installation



*Outside & Inside Vent Cover installed*

**THANK YOU FOR CHOOSING L&W FAB PRODUCTS!**